

101. Recommended spare parts: DW

50/60 Hz


Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: (____)
	Fax number: (____)

Pump information

Quotation made by

Type		Prod. No.	
P.c.	ø	mm	No.
▽	T	°C	IP
Model		Pol	Hz
P ₁ /P ₂	kW	I _N	A _{start} A _N /min
Cosφ		Weight	kg
Ex			



 CH-6105 Schachen

Company name:

Prepared by: (____)

Phone number: (____)

Fax number: (____)

Date: (____)

Quote number:

Recommended spare parts

	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years	5 years	2 years	5 years	2 years	5 years	
Kit - Spare - Bulk	units per pump	units per pump	units per pump	units per pump	units per pump	units per pump	
Kit, Shaft seal	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Wear Parts	0	1	0	2	0	4	
Kit, Repair	0	1	0	2	0	4	
Oil ¹⁾	1	2	2	3	4	8	

1) See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.

96488862 06.2022

GRUNDFOS Holding A/S
Poul Due Jensens Vej 7
DK-8850 Bjerringbro
Tel: +45 87 50 14 00
www.grundfos.com

GRUNDFOS 